

REF · WEB055

Brima

Floor polish for treated wood floors.



DESCRIPTION

Concentrated high-performance polish for treated wood floors, especially parquet. Self-shining and non-slip, with high resistance to scratching from foot traffic and to washing with water and detergents.

DOSAGE AND USE INSTRUCTIONS

Apply concentrated. The surface to be treated is first cleaned with a wet dishcloth. Once dry, the product is applied leaving a uniform film. Using an applicator or discloth is recommended, never a mop or shammy. Let it dry for 20 - 30 minutes and apply a second layer. If applied on a damaged surface or if greater shine is required, a third layer can be applied.

TECHNICAL DATA

Appearance Opaque beige liquid.

pH 9.0 +/- 0.5

MAIN COMPONENTS


Contains non-ionic surfactants < 5 %. Dibutyl phthalate.

PRESENTATION

10 kg.

USE OR HANDLING PRECAUTIONS

DANGER



DO NOT SWALLOW

H360Df May damage the unborn child. Suspected of damage fertility.

H319 Causes serious eye irritation.

H315 Causes skin irritation.

H412 Harmful to aquatic life with long lasting effects.

P102 Keep out of reach of children.

P201-P202 Obtain special instructions before use. Do not handle until all safety precautions have been read and understood.

P280 Wear protective gloves, clothing and eye protection. In case of inadequate ventilation wear respiratory protection.

P363 Wash contaminated clothing before reuse.

P303+P361+P353 IF ON SKIN (or hair): Take off immediately all contaminated clothing. Rinse skin with water [or shower]

P305+P351+P338 IF IN EYES: Rinse cautiously with water for several minutes. Remove contact lenses, if present and easy to do. Continue rinsing.

P308+P313 IF exposed or concerned: Get medical attention.

P501a Dispose of contents/container in a safe way.

MANUFACTURER

Detervic S.A.

Polígon Industrial Can Malloles · Sant Llorenç Desmunts, 32
08500 Vic · Barcelona

ES · CA · EN · FR · PT

DOCUMENT CONTROL

Rev. 9
Issued: 08/10/2025
Page 1 / 2

SALES CONTACT

T. +34 938 891 344
info@instaquim.com
instaquim.com

EUH208

Contains 2-methylisothiazol-3(2H)-one, Reaction mass of 5-chloro-2-methyl-2H-isothiazolin-3-one [EC 247-500-7] and 2-methyl-2H-isothiazol-3-one [EC 220-239-6] (3:1), Tetraamminezinc(2+) carbonate, 1,2-benzisothiazol-3(2H)-one. May produce an allergic reaction.

Do not mix with other chemicals.

Consult the Safety Data Sheet (SDS) before using the product.

MANUFACTURER

Detervic S.A.

Polígon Industrial Can Malloles · Sant Llorenç Desmunts, 32
08500 Vic · Barcelona

ES · CA · EN · FR · PT

DOCUMENT CONTROL

Rev. 9

Issued: 08/10/2025

Page 2 / 2

SALES CONTACT

T. +34 938 891 344

info@instaquim.com

instaquim.com