

REF · WEB011

Deterbrill

Rinse aid for hard water



DESCRIPTION

Rinsing additive for use in the last rinse, specially designed for automatic washing of glassware. Incorporates high-efficiency drying and anti-foaming agents, preventing the formation of scale deposits and giving an excellent shine and total transparency. Does not leave residual smells or flavours that could contaminate the washed items.

DOSAGE AND USE INSTRUCTIONS

Dosage ranges from 0.1 to 0.5 g/l, at a temperature between 65 and 80°C. Automatic dosing is recommended for a better performance.

TECHNICAL DATA

Appearance Transparent blue liquid.

pH 2.5 +/- 0.5

MAIN COMPONENTS

Contains non-ionic surfactants 5-15 %. C10-C12-alcohol ethoxylated/propoxylated.

PRESENTATION

10 kg, 20 kg.

USE OR HANDLING PRECAUTIONS

ANGER



DO NOT SWALLOW	
H318	Causes serious eye damage.
P102	Keep out of reach of children.
P262	Do not get in eyes, on skin, or on clothing.
P305+P351+P338	IF IN EYES: Rinse cautiously with water for several minutes. Remove contact lenses, if present and easy to do. Continue rinsing.
P310	Immediately call a POISON CENTER or doctor.
	Do not mix with other chemicals.

Consult the Safety Data Sheet (SDS) before using the product.

MANUFACTURER

Detervic S.A.

Polígon Industrial Can Malloles · Sant Llorenç Desmunts, 32
08500 Vic · Barcelona

ES · CA · EN · FR · PT

DOCUMENT CONTROL

Rev. 9
Issued: 27/02/2023
Page 1 / 1

SALES CONTACT

T. +34 938 891 344
info@instaquim.com
instaquim.com